

# 03 ROLLTOP BAG

Set  
includes:

PATTERN  
MAIN BODY/WATERPROOF FABRIC  
THE ADDITIONAL PIECE OF FABRIC  
FOR TEMP. TESTS

SEAM SEALING TAPE  
AWESOME, LIMITED TAG  
WEBBING  
FASTEX BUCKLE

## 02

### Materials needed

- SEWING MACHINE OR NEEDLE AND THREAD
- SCISSORS
- LIGHTER
- IRON

## 03

### Instruction

- 1 PRINT** : Print and attach the pattern to a firm board or piece of cardboard (best: using spray glue).
- 2 MAIN BODY** : Cut out the main body pattern from the fabric.
- 3 FOLD** : Fold the fabric along the marked folding line.
- 4 SEW** : Sew the sides marked as (2) together.
- 5 UNWINDING** : Fold the fabric outside (!) along the lines marked as (3) and sew it in place.
- 6 WEBBING** : Attach the webbing for the roll top closure and remember to add the tab as indicated on the pattern. Leave approximately 4 cm of the free end.
- 7 BUCKLE** : Slide one part of the fastex buckle onto the webbing and secure it to the main fabric.
- 8 SEW** : Sew the webbing all the way to the opposite seam.
- 9 SECURE THE BUCKLE** : Secure the second part of the fastex buckle.
- 10 SECURE THE WEBBING** : Secure the end of the webbing.
- 11 IRONING** : Test seam sealing: Set your iron's temperature to the lowest setting. Test seam sealing by using the provided piece of fabric and tape. Gradually raise the temperature until the tape starts to bond with the material, but be careful not to melt the material.
- 12 TAPING** : Attach the seam sealing tape along the seams, making sure to overlap the end of the seam with the tape for a waterproof seal.

- PRO TIP** : TO MAKE YOUR DRY BAG EVEN MORE DURABLE YOU CAN DOUBLE-STITCH THE SEAMS. THIS HELPS PREVENT LEAKS.

## 04

### And that's it!

Your OWN UNIQUE rolltop dry bag is now complete!

